

The Pioneer for Sheet resistance/Resistivity measurement

Model : CRN-100

Non-contact Ultra-High range sheet resistance measurement system



CRN-100 : Non-contact Ultra-High range sheet resistance measurement system measures

Ultra-High range sheet resistance : 10⁹ ~ 10¹⁵ ohm/sq

without contacting (Corona discharge method).

The probe is composed of a grid type corona charger and a surface voltmeter located next to the charger. A test material was placed below the probe without contact to the material at a gap of 2 mm.

Epoch-making measurement system for Ultra-High range sheet resistance by Non-contact

Feature and function

*Ultra-High range sheet resistance measurement

for $10^9 \sim 10^{15}$ ohm/sq without contacting.

- *Mapping program software
- Arranged in a multipoint pattern measurement is programmed
- 2-D, 3-D mapping software
- *Easy operation by Windows 7 system software
- *Measurement data base link with Excel via CSV format file

<Corona discharge method>

Joint development with Yamagata Univ. (Associate Professor : Toshiyuki Sugimoto) Obtain a patent [Pat.No.5510629]

Applications

Any sample within the measurement range can be measured.

- Thin film layer (a-Si, IGZO etc)
- Coating material
- Semiconductor material
- Approximate material as Insulator
- *Please contact us for demo measurement.

Sample sizes

Size : ~ 300x400mm (or more larger) Thickness : ~ 2mm *We can design as your requirement. Please contact us for customize.

A global leading company for resistivity measurement system.





Software Interface





2-D Mapping About [Corona discharge method]





- (1) Unipolar corona ions are supplied to the surface of the test specimen.
- (2) The surface of the test specimen is partly charged.
- (3) The surface charge is traveled through the surface toward an area of lower surface potential.
- (4) The surface potential rise time is measured by the surface voltmeter(detector.)
- (5) This rise time depends on the surface resistance of the materials.

Notice: Expected measurement range of sheet resistance is 10⁹ to 10¹⁵ ohm/sq.

Feature of this method;

- 1 : The measurement is not affected from surface conditions of specimen such as sparseness oxide layer.
- 2 : The surface of the specimen is not damaged.
- 3 : The measurement is not affected by the contact resistance.

☆ Please visit our website for the movie of this system.

*Please contact us for more details.

*The customers are always welcome to do Demo measurement. *Specification subject to change without notice.



NAPSON CORPORATION

<Head Office>Momose Bldg. 2-3-6, Kameido, Koto-ku, Tokyo 136-0071 Japan TEL: +81-3-3636-0286 / FAX: +81-3-3636-0976 info@napson.co.jp www.napson.co.jp